

iMusthav[®]


MV200 MINI FACIAL REMOVER

QUICK START GUIDE

1. Remove cap by pressing on one side of the cap.



2. Rotate the rotary switch to "ON" position.



3. Move in circular motion to remove hairs.



Installing / Changing Battery

1. Rotate the lower rotary switch counterclockwise to "OPEN" position.
2. Insert 1 piece of alkaline AAA battery into the compartment, making sure, the positive pole (+) is facing the bottom of the unit.
3. Rotate the lower rotary switch clockwise to "OFF" position.



How to use the facial trimmer

- Remove the cap.
- Rotate the lower rotary switch clockwise to "ON" position.
- The built-in 360° LED illuminated bezel around the head will automatically turn on to allow clear visibility of fine hairs.
- Gently press the head of the unit against your skin. The unit should not be on an angle.
- Proceed making small circular motions to remove unwanted hairs.



Cleaning



Your trimmer is designed to give you years of comfortable use. To ensure that you get optimal performance from your trimmer, follow these simple cleaning tips:

- Turn the trimmer off.
- Detach the rotating hair removal head by turning it counter-clockwise to the unlocked position and pulling it off.
- After each use, clean the head by using a brush (included) to wipe away the accumulated hair residue.
- Empty any hair from the body of the unit by turning it over and gently tapping the sides.
- After cleaning, put the hair removal head back to its original position on the unit and turn clockwise to the locked position.
(Do not rinse trimmer head nor submerge unit under water)

Caution

- Keep out of reach of children.
- Do not use on irritated skin or areas where there are pimples or acne. Discontinue use if skin irritation occurs.
- Exercise caution when using around eyes.
- Do not rinse trimmer head under water. Do not submerge unit under water.
- Store in a cool dry place when not in use. Do not dispose in fire.

Patent Pending. Designed in the United Kingdom. Assembled in China. Distributed by Nice Assets Limited Hong Kong . info@niceassets.hk MV200D20201023

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Dispose of old batteries



■ If your product is marked with this symbol, it means that used electrical/electronic products should not be mixed with general household waste. Dispose of old batteries according to all applicable local regulations,

iMusthav[®]

MV200 MINI FACIAL HAIR REMOVER

Facial Trimmer - Hypoallergenic 18 Karat gold plated blade

